


*Sun*  
**INSIDE  
APPROACH**  
GOLF TRAINING SERIES

*"The Inside Approach helps you to swing properly. It's simple,  
easy to use and can help golfers of all skill levels."*

*- Jack Nicklaus*



# SLICE CORRECTION TRAINER

The Simple Solution to Straighter Drives  
INSTRUCTIONAL MANUAL

Congratulations on purchasing the Inside Approach® SLICE CORRECTION TRAINER. You'll soon benefit from the most effective swing trainer on the market. In just a few swings, you'll have a clear understanding of where the club needs to be swung as it approaches the ball, and you'll immediately see improvement in both the distance and accuracy of your shots.

To get the most out of your Inside Approach SLICE CORRECTION TRAINER, please view the Instructional DVD before you first try the product. In this DVD, you will not only learn how to correctly use the swing trainer, but you will gain invaluable golf swing insight and learn how to solve common pitfalls that often occur when learning new swing motions.

Remember, golf is just a game. The goal is to have fun. I'm certain that by using the Inside Approach SLICE CORRECTION TRAINER, you'll be on your way to better shots and more enjoyable rounds of golf.




Best regards,  
*Jim Sowerwine*


## ASSEMBLY INSTRUCTIONS

1. Remove all parts from packaging and familiarize yourself with each one. (Please ensure all parts are included by referencing to the Parts List and Exploded Diagram on page 2.)
2. Assemble the "legs" (#1034-01B) to the "3-hole connector" (#1033-01B) as shown."
3. Assemble the "snap-on-clip" (#1031-01B) to the "neck" (#1032-01B).
4. Assemble the "neck" (#1032-01B) to the "3-hole connector" (#1033-01B).
5. IMPORTANT: Slide "cushion" (#1036-01B) out to black line on post before use. (See Exploded Diagram.) This extended cushion length provides maximum effectiveness for promoting an inside swing path.

## EXPLODED DIAGRAM



SLIDE CUSHION TO LINE ON POST




## PARTS LIST

### Inside Approach unit #101B

PART DESCRIPTION	PART NUMBER	# OF PARTS
Cushion post	#1035-01B	1
Cushion	#1036-01B	1
Snap-on-clip	#1031-01B	1
Neck	#1032-01B	1
3-hole connector	#1033-01B	1
Legs	#1034-01B	2








## SETTING UP THE INSIDE APPROACH

- After assembling the Inside Approach, aim the cushion directly away from your target.
- Place the ball directly under the cushion's snap-on-clip. Misplacing the ball to either side of the snap-on clip may cause inadvertent damage to the product or your club!
- Align yourself parallel to the cushion.
- Using any club, begin to make swings. (It's most effective with the woods and longer irons.)
- The goal is to hit shots without hitting the cushion.



**Helpful Tip:** First time use may be a little intimidating. We recommend making a few practice swings before immediately hitting balls. First, place a tee (without the golf ball) into the ground directly under the snap-on-clip. Make a few swings, at 50% effort, until you can consistently clip the tee out of the ground without contacting the cushion or hitting the ground before the tee. Once you have a feel for clipping the tee consistently, place a ball on the tee and

make the same 50% effort swing. Gradually work your way into full swings. Keep in mind, it is much more effective to learn a new motion at slower speeds than it is at full speed.



## COMMON SWING PROBLEMS

Most errant shots are a result of poor path as the club approaches the ball. The INSIDE APPROACH SLICE CORRECTION TRAINER will help you identify and imprint the correct 'inside' path allowing you to consistently hit longer, straighter, more accurate shots.

The first key to correcting your swing path is to diagnose the symptoms of your most common errant shots.

### Fault: Pulling Shots

In a pulled shot the ball starts left (right-handed golfers) of your intended target. If you are hitting 'pulls', then you are swinging the club from out-to-in as the club approaches the ball.

### Fault: Slicing the Ball

A slice is a ball flight that curves to the right (right-handed golfers). If you consistently slice the ball, your club face is open at impact, imparting a side spin on the golf ball. The most common reason the club face stays open is because the path of the club is approaching the ball on too 'steep' of an angle or is approaching the ball from out-to-in. This out-to-in swing path usually restricts your ability to square the club face at impact.

### Fault: Pop-Ups

A pop-up is a shot that is hit high on the club face and goes almost straight up in the air, not traveling very far. It is caused by a swing that has too "steep" of an angle as the club approaches the ball.



## The Cure: Pulls, Slices and Pop-Ups

Learn to swing the club more from the 'inside' as it approaches the ball.

**Helpful Tip:** If you successfully hit the ball without hitting the cushion and the ball is still slicing or curving, try to strengthen your grip. (For right-handed golfers, rotate your left hand more to the right until the V formed between your thumb and forefinger points towards your right shoulder. Additionally, make sure to soften your grip pressure). Be sure to watch the instructional video as we specifically address this and other invaluable golf swing fundamentals.

## Fault: Pushes and Blocks

A push or a block is a ball flight that starts to the right (right-handed golfers) of your intended target and keeps its course. If your tendency is to hit pushes or blocks, then the club is swinging too far from the inside as it approaches the ball.

## Fault: Hooking the Ball

A hook is a ball flight that curves to the left (right-handed golfers), the result of a closed club face at impact. If you consistently hit hooks, then there is a good chance you swing the club too far from the inside as it approaches the ball. When this happens, the hands and arms have a tendency to rotate too quickly, causing the club face to be closed at impact.

## The Cure: Pushes, Blocks and Hooks

Learn to swing the club on the 'correct' inside path. Do not allow the club to get too far from the inside or underneath the plane. Practice using the Inside Approach as pictured here.





## 30-Day Warranty

Sowerwine Golf Solutions, LLC, the manufacturer, will warrant the product against defects in material and workmanship for a period of 30 days. This warranty applies only when the sale of the product is for personal or household use, but not when the sale or any resale is for commercial use.

In the event of failure of this product to conform to this warranty during the warranty period, Sowerwine Golf Solutions, LLC will repair or replace, at its own option, the product or any covered part. This warranty does not cover damage caused by accident, or repairs or attempted repairs by any person not authorized by Sowerwine Golf Solutions, LLC, or by vandalism, misuse, abuse, or alteration. This warranty is nontransferable.

In order to obtain service under this warranty, use the following procedure. Call customer service at 1-877-777-3776. A customer service representative will determine whether parts will be replaced or repaired and will advise you of the address of where to send the product.

This warranty is limited solely to the above and this warranty and any warranties implied by state law will apply only for the time period set forth above. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. Sowerwine Golf Solutions, LLC will not be liable for any loss or damage, including incidental or consequential damages of any kind, whether based upon warranty, contract or negligence, and arising in connection with the sales, use or repair of the product. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE.

**Want to improve your golf game further?** Check out Jim Sowerwine's DVD Lesson Library including these top selling DVD's available at [www.insideapproach.com](http://www.insideapproach.com)

**"Advanced Drills"** - Features tour players and Top 50 instructors' drills for fades, draws and shaping shots!

**"Secret Lessons From The Tour"** - Pure instruction from Tour players and the Tour players' instructors. Lessons are competition-tested and have led to Tour victories!

To order call **877-777-3776** or visit [www.insideapproach.com](http://www.insideapproach.com)

© 2006 Inside Approach is a registered trademark of Sowerwine Golf Solutions, LLC. U.S. Patent 7,029,401

## FREQUENTLY ASKED QUESTIONS

Q: Where do I place the ball in reference to the Inside Approach?

A: After completing assembly of the Inside Approach, place the ball directly beneath the Snap-on-Clip (#1031-01B).

Q: Where do I get replacement parts?

A: Go to [www.insideapproach.com](http://www.insideapproach.com) and click on the "Replacement Parts" link.

Q: Can the Inside Approach be used for both left and right-handed golfers?

A: Yes, it is specifically designed so that the cushion can be rotated to either side.

Q: Which golf clubs can I use with the Inside Approach? Will it damage my clubs if I hit the cushion?

A: The Inside Approach works with any club in your bag and as long as you use the Inside Approach as it is intended to be used, your clubs will not be damaged. The proprietary design allows the cushion to safely break away upon contact with the club.

Q: For whom or what type of golfers is the Inside Approach designed?

A: The Inside Approach helps golfers of all skill levels - from beginners to Tour Players.

Q: Can the Inside Approach be used indoors?

A: It can be used anywhere you can safely swing a golf club.

Q: Can the ball still "slice" even if I miss the cushion?

A: If you miss the cushion, your club is now approaching the ball from the "inside"...if your ball is still slicing - review the instructional video and the manual that addresses the grip.

